

RICOH CX1

Firmware Update Instruction Manual

This manual explains the procedures for downloading the CX1 firmware from the Ricoh website and updating the camera's firmware.


Perform the following operations to update the firmware.

1. Check the firmware version




Caution

Before updating, be sure to check the firmware version through the following method. If the installed firmware is the latest version, there is no need to update.

1. **Making sure that the camera's power is turned off, switch the mode dial to SCENE.**
2. **While pressing the ADJ./OK button ▼, hold down the  (Playback) button for 2-3 seconds.**
 - The firmware version will be displayed on the picture display for about 20 seconds.
3. **Check the firmware version displayed on the picture display.**

- e.g. When the firmware version is V1.00, the version will be shown as [MAIN : V 1.00] as follows:

MAIN : V 1.00
BKUP : V X.XX
MONI : V X.XX
ADJD : V X.XX
EXTD : V X.XX
CPU1 : V X.XX
SH : XXXXXX
ST : XXXXXX




2. Extract the firmware

1. Download the firmware from the Ricoh website.
2. Double-click or right-click and select [Open] on the downloaded file.
 - A dialog screen appears.
3. Click [OK].
 - The folder [CX1 Update] is created, and the firmware is extracted to the folder [Firmware relX.XX (where X.XX is the version number)]. Check that [flaunch3] (firmware file) and [flaunch8] (adjusted value file) are inside the folder [Firmware relX.XX].

For Windows



For Macintosh



3. Copy the firmware to an SD memory card

There are two ways to copy the firmware into an SD memory card.

- With an SD memory card loaded in the camera, connect the camera and computer with the provided USB cable, and copy the firmware to the SD memory card
- Using a card reader or a card writer, copy the firmware to an SD memory card (a card reader or card writer is required)

To copy the firmware by connecting the camera and computer with the USB cable

1. If DC Software is installed on your Windows PC, check that DL-10 is not active.
2. If DL-10 is active, right-click on the DL-10 icon in the task bar, and click [Exit].
 - If the DL-10 icon is not displayed in the task bar, you do not need to perform Step 2.
3. Load a battery with adequate remaining power into the camera.
4. Load the SD memory card into the camera, and turn the power on.
5. Display the camera's Setup menu, select [Format [Card]], and press the ADJ./OK button ►.

6. Select [Yes], and press the ADJ./OK button.

- The SD memory card is formatted.

Caution

If you format a card that still has images stored on it, the images will be lost. Save the images you do not want to erase in your computer before formatting the card.

7. Turn the camera off, and connect the camera and computer with the provided USB cable.

- The camera turns on automatically. If the camera does not turn on automatically, press the POWER button and turn the power on.
- If DC Software is installed in your Windows PC, DL-10 may automatically start up. In this case, exit DL-10.
- Click [Cancel] if the [Removable Disk] dialog appears in Windows XP or Windows Vista.
- If iPhoto starts up in Mac OS X, exit iPhoto.

8. Copy the files [flaunch3] and [flaunch8] (created when the firmware was extracted) into [RICOHDCX] root directory in [My Computer].

- The camera's drive name may differ depending on the OS you are running.
e.g. [Removable Disk], etc.

For Windows



For Macintosh



9. Open [RICOHDCX] in [My Computer], and confirm that the files have been copied.

10. For Windows

When the copying of the firmware is completed, double-click the [Safely Remove Hardware] icon in the task bar.

For Macintosh

Drag and drop the [RICOHDCX] icon to the [Trash] icon. Once the icon has disappeared, proceed to Step 14.

Caution

If you skip the procedures in Step 10, the firmware copy may not be successful.

11. Select [USB Mass Storage Device], and click [Stop].

12. Click [OK].




To copy the firmware using a card reader or a card writer to an SD memory card


- 

If you format a card that still has images stored on it, the images will be lost. Save the images you do not want to erase in your computer before formatting the card.

- 4

4. Update the firmware

1. Making sure that the camera's power is turned off, switch the mode dial to SCENE.
2. While pressing the ADJ./OK button ▲, hold down the  (Playback) button for 2-3 seconds.
 - A confirmation message for the firmware update is displayed on the picture display.
3. Press the ADJ./OK button ► to select [Yes], and press the ADJ./OK button.
 - The firmware update starts, and the following message is displayed on the picture display.
[Checking rewrite file]
[Rewriting program]
4. The camera automatically turns off and restarts.



Note

- If the message [Incorrect rewriting file] is displayed and the camera is automatically turned off, check the camera model again and retry the update using the correct firmware.
- The firmware file copied to the SD memory card is deleted when you format the SD memory card. Delete the file if necessary.