






























PENTAX KP**PENTAX K-3 III**

 1	Custom Image	
	AF with Viewfinder	AF Mode
		AF Active Area
		AF.S Setting
		1st Frame Action in AF.C
		Action in AF.C Cont.
	AF with Live View	AF Active Area
		Focus Peaking
		AF.S Setting
	AF Assist Light	
AE Metering		
ISO AUTO Setting	AUTO ISO (Maximum)	
	AUTO ISO (Minimum)	
	ISO Sensitivity Options	
	Minimum Shutter Speed	
Program Line		
Exposure Mode USER		
 2	Shutter Mode Selection	
	Image Capture Settings	File Format
		JPEG Recorded Pixels
		JPEG Quality
		RAW File Format
		Color Space
	D-Range Settings	Highlight Correction
		Shadow Correction
	Noise Reduction	Slow Shutter Speed NR
		High-ISO NR
 3	Clarity	
	Skin Tone	
	Digital Filter	
	HDR Capture	
	Pixel Shift Resolution	Pixel Shift Resolution
		Motion Correction
ASTROTRACER	ASTROTRACER	
	Precise Calibration	
 4	AA Filter Simulator	
	Shake Reduction	
	Horizon Correction	
	Composition Adjust.	

 6	Custom Image	
	 1	AF Mode
		AF Active Area
		AF.S Setting
		1st Frame Action in AF.C
		Action in AF.C Cont.
	 1	AF Active Area
		Face Detection
		Focus Peaking
	Contrast AF Options	
 1 AF Assist Light		
 2 AE Metering		
 2	ISO Sensitivity Setting	ISO Auto Upper Limit
		ISO Auto Lower Limit
		Min. Shutter Speed Op.
		ISO Auto with Min. Speed
		Minimum Shutter Speed
 2 Program Line		
 C 1 Exposure in User Mode		
/		
 5 File Format		
 5 JPEG Recorded Pixels		
 5 JPEG Quality		
 5 RAW File Format		
 5 Color Space		
 6	D-Range Correction	Highlight Correction
		Shadow Correction
 6	Noise Reduction	Slow Shutter Speed NR
		High-ISO Noise Reduction
 6 Clarity		
 6 Skin Tone		
 6 Digital Filter		
 4 HDR Capture		
 4 Pixel Shift Resolution		
 4	ASTROTRACER	ASTROTRACER
		Precise Calibration
 4 AA Filter Simulator		
 7 Shake Reduction		
 7 Auto Horizon Correction		
 7 Composition Adjustment		

PENTAX KP




























PENTAX K-3 III

4	Lens Correction	Distortion Correction
		Peripheral Illumin. Corr.
Lat-Chromatic-Ab Adj		
Diffraction Correction		
Input Focal Length		
5	Viewfinder Overlay	Electronic Level
		Superimpose AF Area
Live View	Grid Display	
	Electronic Level	
	Histogram Display	
	Highlight Alert	
	Flicker Reduction	
Instant Review	Display Time	
	Zoom Review	
	Save RAW Data	
	Delete	
	Histogram Display	
	Highlight Alert	
Other Display Settings	Guide Display	
	Display Color	
Button Customization	Fx1 Button	
	Fx2 Button	
	Fx3 Button	

6	Lens Correction	Distortion Correction	
		Peripheral Illumin. Corr.	
		Lat-Chromatic-Ab Adj	
		Diffraction Correction	
MF Lens Focal Length			
C 4	Viewfinder Display	[Viewfinder Screen └[F1 Customization [F2 Customization [F3 Customization [F4 Customization	
		Electronic Level Type	
C 4	Viewfinder Display	[Viewfinder Screen └[F1 Customization [F2 Customization [F3 Customization [F4 Customization	
		Viewfinder Light	
C 4	Monitor Display	[Live View └[Shooting Info Display └[L1 Customization [L2 Customization [L3 Customization	
		Grid Guide	
		[Live View └[Shooting Info Display └[L1 Customization [L2 Customization [L3 Customization	
		[Live View └[Electronic Level Type	
		[Live View └[Electronic Level Design	
		[Live View └[Shooting Info Display └[L1 Customization [L2 Customization [L3 Customization	
	[Live View └[Shooting Info Display └[L1 Customization [L2 Customization [L3 Customization		
	[Live View └[Flicker Reduction		
	C 4	Instant Review	Display Time
			Zoom Review
Save RAW (RAW Button)			
Delete Img. (Delete Btn.)			
Histogram			
2	Guide Display		
	C 4 Monitor Display	Color Settings	
C 2	Fx Button		

PENTAX KP

PENTAX K-3 III

 5	Button Customization	AF/AE-L Button	 2	AF/AE Lock Settings			
		Function Dial		 2	Smart Function		
		E-Dial Programming			 2	E-Dial Programming	Still Image
	Memory						Rotation Direction
 1	Save USER Mode	Save Settings	 5	Memory			
		Rename USER Mode		 1	Save User Mode Settings		
		Check Saved Settings			 1	Rename User Mode	
		Reset USER Mode					
 1	Custom Image		 1	Reset User Mode Settings			
	AF with Live View	AF Mode		 6	Custom Image		
		AF Active Area			 1	AF with Live View	Movie Mode AF
		Focus Peaking					AF Active Area
	AF Assist Light			 1	Focus Peaking		
	AE Metering			 2	AF Assist Light		
	Movie Capture Settings	Recorded Pixels		 5	AE Metering		
		Framerate		 5	Recorded Pixels		
	Recording Sound Level			 5	Framerate		
	 2	D-Range Settings		Highlight Correction	 5	Recording Sound Level	
Shadow Correction			 6	D-Range Correction		Highlight Correction	
Digital Filter		 6		Shadow Correction			
Movie SR		 7	Digital Filter				
 2	Live View	Grid Display	 4	Shake Reduction			
				Electronic Level	Monitor Display	[Live View]	[]
		Histogram Display				↳[Shooting Info Display]	[]
				Highlight Alert		↳[L1 Customization]	[]
						Flicker Reduction	[L2 Customization]
				[L3 Customization]			[]
		Grid Guide					
		[Live View]					
		↳[Shooting Info Display]					
		↳[L1 Customization]					
		[L2 Customization]					
		[L3 Customization]					
		[Live View]					
		↳[Electronic Level Type]					
		[Live View]					
		↳[Electronic Level Design]					
		[Live View]					
		↳[Shooting Info Display]					
		↳[L1 Customization]					
		[L2 Customization]					
		[L3 Customization]					
		[Live View]					
		↳[Shooting Info Display]					
		↳[L1 Customization]					
		[L2 Customization]					
		[L3 Customization]					
		[Live View]					
		↳[Flicker Reduction]					
 5	Button Customization	AF/AE-L Button	 2	AF/AE Lock Settings			
		E-Dial Programming		 2	E-Dial Programming	Movie	

















PENTAX KP

PENTAX K-3 III

▶ 1 Slideshow		▶ 2 Protect	Protect All Images
Protect All Images		▶ 2 Delete	Delete All Images
Delete All Images		C 4 Zoom Review	Quick Zoom
Quick Zoom		▶ 1 Playback Sound Volume	
Playback Sound Volume	Auto Image Rotation	▶ 1 Auto Image Rotation	
LCD Display	Grid Display	C 4 Monitor Display	[Playback Info Display] └[Standard Info. Display] [No Information Display]
	Highlight Alert		Grid Guide
			[Playback Info Display] └[Standard Info. Display] [No Information Display]
↶ 1 Language/言語		↶ 7 Language/言語	
Date Adjustment		↶ 7 Date Adjustment	
World Time			
Text Size			
Sound Effects		↶ 3 Sound Effects Volume	
		↶ 3 Sound Effects Setting	
↶ 2 LCD Display Settings		↶ 2 Monitor Adjustment	
Outdoor View Setting		↶ 2 Outdoor View Setting	
Night Vision LCD Display		↶ 2 Night Vision Display	
Indicator Lamps		↶ 3 Indicator Lamps	
↶ 3 Wi-Fi		↶ 4 Wireless LAN Setting	
GPS/E-Compass	GPS Time Sync		
	Calibration	↶ 4 GPS Settings	
USB Connection		↶ 4 USB Setting	
Video Out Resolution			
External Input Devices			
Auto Power Off		↶ 5 Auto Power Off	
↶ 4 Create New Folder		↶ 1 Create New Folder	
Folder Name		↶ 1 Folder Name	
File Name		↶ 1 File Name	
File No.	Sequential Numbering	↶ 1 Sequential Numbering	
	Reset File Number	↶ 1 Reset Numbering	
Copyright Information	Embed Copyright Data	↶ 1 Copyright Information	Embed Copyright Data
	Photographer		Photographer
	Copyright Holder		Copyright Holder
Format		↶ 1 Format	
↶ 5 Pixel Mapping		↶ 6 Pixel Mapping	
Dust Removal		↶ 6 Dust Removal	
Sensor Cleaning		↶ 6 Sensor Cleaning	
Select Battery		↶ 5 Battery Grip Settings	
Certification Marks		↶ 6 Certification Marks	
Firmware Info/Options		↶ 6 Firmware Info/Options	
Reset		↶ 8 Reset	

PENTAX KP

PENTAX K-3 III

C 1	EV Steps	C 5	EV Steps
	Sensitivity Steps	C 5	ISO Sensitivity Steps
	Meter Operating Time	C 5	Meter Operating Time
	Auto EV Compensation		2 Auto EV Compensation
	Link AE and AF Point		2 Link AE and AF Point
	AE-L with AF Locked		2 Link AE and AF Point
	Bulb (B) Mode Options	C 2	AF/AE Lock Settings
C 2	Release While Charging	C 5	Bulb (B) Mode Options
	Bracketing Order		4 Drive Mode [Drive] └[Bracketing] └[Bracketing Order]
	One-Push Bracketing		4 Drive Mode [Drive] └[Bracketing] └[One-Push Bracketing]
	Interval Shooting Options		4 Drive Mode [Drive] └[Interval Shooting] [Interval Composite] └[Fixed Time Release]
	AF in Interval Shooting		4 Drive Mode [Drive] └[Interval Shooting] [Interval Composite] └[AF Operation per Shot]
	WB Adjustable Range		3 Auto Adjust. for Source
	AWB in Tungsten Light		3 Auto Adjust. for Source
			3 AWB in Tungsten Light
			3 AWB in Tungsten Light
	C 3	WB When Using Flash	C 6
Color Temperature Steps		C 2	Fx Button
Enable/Disable Control			
4-way Controller Settings			
Auto SR Off			7 Auto Shake Reduction Off
Save Rotation Info			7 Auto Shake Reduction Off
C 4	Catch-in Focus	C 6	Save Rotation Info
	AF Fine Adjustment		2 Store Cursor Position
	Using Aperture Ring		1 AF with Viewfinder Catch-in Focus
	Reset Custom Functions	C 7	AF Fine Adjustment
		C 6	Using Aperture Ring
		8 Reset	