

























PENTAX K-5 II
PENTAX K-5 IIs

PENTAX K-3 III

	1 USER Mode	USER
	Exposure Mode	USER
	File Format	
	JPEG Recorded Pixels	
	JPEG Quality	
	AF Settings	AUTO AF Point Setting Expanded Area AF
	Lens Correction	Distortion Correction Lat-Chromatic-Ab Adj
	2 Cross Processing	
	Extended Bracketing	
	Digital Filter	
	HDR Capture	
	Multi-exposure	
	Interval Shooting	
	Composition Adjust.	Composition Adjust. Recall Previous Position
	3 D-Range Setting	Highlight Correction Shadow Correction
	ISO AUTO Setting	
	High-ISO NR	
	4 Movie	Recorded Pixels Quality Level Sound Cross Processing Digital Filter Movie Aperture Control Shake Reduction
	Live View	Autofocus Method
		Show Grid
		Info Overlay

	1 Recall User Mode Setting	
	1 Exposure in User Mode	
	5 File Format	
	5 JPEG Recorded Pixels	
	5 JPEG Quality	
	1 AF with Viewfinder	AF Active Area
	6 Lens Correction	Distortion Correction Lat-Chromatic-Ab Adj
6 Custom Image		
	6 Digital Filter	
	4 HDR Capture	
	4 Drive Mode	[Drive └[Multi-exposure]
	4 Drive Mode	[Drive └[Interval Shooting]
	7 Composition Adjustment	
	5 Memory	
	6 D-Range Correction	Highlight Correction Shadow Correction
	2 ISO Sensitivity Setting	Slow Shutter Speed NR High-ISO Noise Reduction
		6 Noise Reduction
	2 Program Line	
	5 Color Space	
	5 RAW File Format	
	5 Recorded Pixels	
	5 Framerate	
	5 Recording Sound Level	
	6 Custom Image	
	6 Digital Filter	
	Live View	
	7 Shake Reduction	
	1 AF with Live View	AF Active Area Face Detection
		4 Monitor Display
Grid Guide		
Live View		

PENTAX **K-5 II**
PENTAX **K-5 II S**

PENTAX **K-3 III**

4	Live View	Histogram	4	Monitor Display	[Live View] ↳[Shooting Info Display] ↳[L1 Customization] [L2 Customization] [L3 Customization]	
		Bright/Dark Area			Monitor Display	[Live View] ↳[Shooting Info Display] ↳[L1 Customization] [L2 Customization] [L3 Customization]
	Electronic Level		4	Viewfinder Display	[Viewfinder Screen] ↳[F1 Customization] [F2 Customization] [F3 Customization] [F4 Customization] Electronic Level Type	
	Horizon Correction		4	Monitor Display	[Live View] ↳[Shooting Info Display] ↳[L1 Customization] [L2 Customization] [L3 Customization] [Live View] ↳[Electronic Level Type] [Live View] ↳[Electronic Level Design]	
	Shake Reduction		7	Auto Horizon Correction		
	Input Focal Length		7	Shake Reduction		
	GPS	Electronic Compass	6	MF Lens Focal Length		
		Simple Navigation				
		[ASTROTRACER (Bulb)] ↳[Timed Exposure]			Status Screen	
		[ASTROTRACER (Bulb)] ↳[Exposure Time Preset]			Status Screen	
		[ASTROTRACER (Bulb)] ↳[Precise Calibration]		4	ASTROTRACER	Precise Calibration
		Calibration		4	GPS Settings	
		Positioning Interval				
		Auto Time Synch.				
5	Instant Review	Display Time	4	Instant Review	Display Time	
		Histogram			Histogram	
		Bright/Dark Area			Highlight Alert	
		Enlarge Instant Review			Zoom Review	
	Digital Preview		2	Preview Dial	Digital Preview Settings	
	E-Dial Programming		2	E-Dial Programming		
Button Customization		RAW/Fx Button	2	Fx Button		
		AF Button	2	AF/AE Lock Settings		
		Preview Dial	2	Preview Dial		
		Shutter Button Half Press	2	AF/AE Lock Settings		
	Memory		5	Memory		
Save USER Mode		Save Settings	1	Save User Mode Settings		
		Rename USER Mode	1	Rename User Mode		
		Check Saved Settings				
		Reset USER Mode	1	Reset User Mode Settings		

PENTAX **K-5 II**
PENTAX **K-5 II s**
















PENTAX **K-3 III**

▶ 1	Slideshow	
	Quick Zoom	
	Bright/Dark Area	
	Auto Image Rotation	
	Delete All Images	
↷ 1	Language/言語	
	Date Adjustment	
	World Time	
	Text Size	
	Beep	
	Guide Display	
	Status Screen	Enable
		Auto Screen Rotation
		Display Color
	↷ 2	Brightness Level
LCD Color Tuning		
Video Out		
HDMI Out		
USB Connection		
Folder Name		
Create New Folder		
↷ 3	File Name	
	Copyright Information	Embed Copyright Data
		Photographer
		Copyright Holder
	Auto Power Off	
	Select Battery	Select Battery
		AA Battery Type
Reset		
↷ 4	Pixel Mapping	
	Dust Alert	
	Dust Removal	
	Sensor Cleaning	
	Format	

C 4	Zoom Review	Quick Zoom
	C 4	Monitor Display
▶ 1 Auto Image Rotation		
▶ 2		Delete
↷ 7	Language/言語	
	Date Adjustment	
/		
/		
↷ 3	Sound Effects Volume	
	Sound Effects Setting	
↷ 2	Guide Display	
	Status Screen	INFO
C 4	Monitor Display	[Status Screen] ⌞[Auto Display Rotation]
	C 4	Monitor Display
↷ 2	Monitor Adjustment	
	Monitor Adjustment	
/		
/		
↷ 4	USB Setting	
	Folder Name	
↷ 1	Create New Folder	
	File Name	
↷ 1	Copyright Information	Embed Copyright Data
		Photographer
		Copyright Holder
↷ 5	Auto Power Off	
	↷ 5	Battery Grip Settings
/		
↷ 8	Reset	
	↷ 6	Pixel Mapping
/		
↷ 6	Dust Removal	
	Sensor Cleaning	
↷ 1	Format	

PENTAX **K-5 II**
PENTAX **K-5 II s**

PENTAX **K-3 III**

C 1	EV Steps	C 5	EV Steps	
	Sensitivity Steps	C 5	ISO Sensitivity Steps	
	Expanded Sensitivity			
	Meter Operating Time	C 5	Meter Operating Time	
	AE-L with AF Locked	C 2	AF/AE Lock Settings	
	Link AE to AF Point	 2	Link AE and AF Point	
Auto EV Compensation	 2	Link AE and AF Point		
C 2	Auto Bracketing Order	 2	Auto EV Compensation	
	One-Push Bracketing	 4	Drive Mode	[Drive └[Bracketing └[Bracketing Order]]
	WB Adjustable Range	 4	Drive Mode	[Drive └[Bracketing └[One-Push Bracketing]]
	WB When Using Flash	 3	Auto Adjust. for Source	
	AWB in Tungsten Light	 3	Auto Adjust. for Source	
	Color Temperature Steps	 3	AWB in Tungsten Light	
	Superimpose AF Area	 3	AWB in Tungsten Light	
	C 3	AF.S Setting	C 6	Color Temperature Steps
AF.C Setting		C 4	Viewfinder Display	[Viewfinder Screen └[F1 Customization [F2 Customization [F3 Customization [F4 Customization]]
AF Assist Light		 1		AF with Viewfinder
AF with Remote Control		 1	AF Assist Light	AF.S Setting
Remote Control in Bulb		 1	AF Assist Light	Action in AF.C Cont.
Release While Charging		C 6	AF with Remote Control	
Flash in Wireless Mode		C 5	Bulb (B) Mode Options	
C 4	LCD Panel Illumination	C 4	LCD Panel	Illumination Brightness LCD Panel Illumination
	Saving Rotation Info	C 6	Save Rotation Info	
	Save Menu Location	 2	Store Cursor Position	
	Catch-in Focus	 1	AF with Viewfinder	Catch-in Focus
	AF Fine Adjustment	C 7	AF Fine Adjustment	
	Using Aperture Ring	C 6	Using Aperture Ring	
	Reset Custom Functions	 8	Reset	