






























PENTAX K-70



PENTAX K-3 III

 1	Custom Image	
	Scene Mode SCN	
	AF with Viewfinder	AF Mode
		AF Active Area
		AF.S Setting
		1st Frame Action in AF.C
		Action in AF.C Cont.
	AF with Live View	AF Active Area
		Focus Peaking
		AF.S Setting
AF Assist Light		
AE Metering		
Exposure Mode USER		
 2	Image Capture Settings	File Format
		JPEG Recorded Pixels
		JPEG Quality
		RAW File Format
		Color Space
D-Range Settings	Highlight Correction	
	Shadow Correction	
Noise Reduction	Slow Shutter Speed NR	
	High-ISO NR	
 3	Clarity	
	Skin Tone	
	Digital Filter	
	HDR Capture	
	Pixel Shift Resolution	
	ASTROTRACER	ASTROTRACER
		Precise Calibration
 4	AA Filter Simulator	
	Shake Reduction	
	Horizon Correction	
	Composition Adjust.	
	Lens Correction	Distortion Correction
		Peripheral Illumin. Corr.
		Lat-Chromatic-Ab Adj
		Diffraction Correction
Input Focal Length		

 6	Custom Image	
	 1	AF Mode
		AF Active Area
		AF.S Setting
		1st Frame Action in AF.C
		Action in AF.C Cont.
	 1	AF Active Area
		Face Detection
		Focus Peaking
Contrast AF Options		
 1 AF Assist Light		
 2 AE Metering		
 1 Exposure in User Mode		
 5 File Format		
 5 JPEG Recorded Pixels		
 5 JPEG Quality		
 5 RAW File Format		
 5 Color Space		
 6	D-Range Correction	Highlight Correction
		Shadow Correction
 6	Noise Reduction	Slow Shutter Speed NR
		High-ISO Noise Reduction
 6 Clarity		
 6 Skin Tone		
 6 Digital Filter		
 4 HDR Capture		
 4 Pixel Shift Resolution		
 4	ASTROTRACER	ASTROTRACER
		Precise Calibration
 4 AA Filter Simulator		
 7 Shake Reduction		
 7 Auto Horizon Correction		
 7 Composition Adjustment		
 6	Lens Correction	Distortion Correction
		Peripheral Illumin. Corr.
		Lat-Chromatic-Ab Adj
		Diffraction Correction
 6 MF Lens Focal Length		




PENTAX *K-70*














PENTAX *K-3 III*

 5	Viewfinder Overlay	Electronic Level	C 4	Viewfinder Display	[Viewfinder Screen] └[F1 Customization] [F2 Customization] [F3 Customization] [F4 Customization]
		Superimpose AF Area		Viewfinder Display	[Viewfinder Screen] └[F1 Customization] [F2 Customization] [F3 Customization] [F4 Customization]
Live View	Grid Display	Electronic Level	C 4	Monitor Display	[Live View] └[Shooting Info Display] └└[L1 Customization] [L2 Customization] [L3 Customization]
					Grid Guide
	Histogram Display	[Live View] └[Shooting Info Display] └└[L1 Customization] [L2 Customization] [L3 Customization]			
	Highlight Alert	[Live View] └[Shooting Info Display] └└[L1 Customization] [L2 Customization] [L3 Customization]			
	Flicker Reduction	[Live View] └[Flicker Reduction]			
Instant Review	Display Time		C 4	Instant Review	Display Time
	Zoom Review				Zoom Review
	Save RAW Data				Save RAW (RAW Button)
	Delete				Delete Img. (Delete Btn.)
	Histogram Display				Histogram
	Highlight Alert				Highlight Alert
Other Display Settings	Guide Display		 2	Guide Display	
	Display Color		C 4	Monitor Display	Color Settings
Button Customization	Fx1 Button		C 2	Fx Button	
	Fx2 Button				
	AF/AE-L Button			AF/AE Lock Settings	
	E-Dial Programming			C 2	E-Dial Programming
Memory			C 5	Memory	

PENTAX K-70

PENTAX K-3 III

 5	Save USER Mode	Save Settings
		Rename USER Mode
		Check Saved Settings
		Reset USER Mode
 1	Custom Image	
	AF with Live View	AF Mode
		AF Active Area
		Focus Peaking
	AF Assist Light	
	AE Metering	
	Movie Capture Settings	Recorded Pixels
		Framerate
	Recording Sound Level	
	 2	D-Range Settings
Shadow Correction		
Digital Filter		
Movie SR		
Live View	Grid Display	
	Electronic Level	
	Histogram Display	
	Highlight Alert	
	Flicker Reduction	
	Button Customization	AF/AE-L Button
E-Dial Programming		

 1	Save User Mode Settings	
	Rename User Mode	
 1	Reset User Mode Settings	
 6	Custom Image	
	AF with Live View	Movie Mode AF
		AF Active Area
Focus Peaking		
 1	AF Assist Light	
 2	AE Metering	
 5	Recorded Pixels	
 5	Framerate	
 5	Recording Sound Level	
 6	D-Range Correction	Highlight Correction
		Shadow Correction
 6	Digital Filter	
 7	Shake Reduction	
 4	Monitor Display	[Live View]
		↳[Shooting Info Display]
		↳[L1 Customization]
		[L2 Customization]
		[L3 Customization]
	Grid Guide	
	[Live View]	
	↳[Shooting Info Display]	
	↳[L1 Customization]	
	[L2 Customization]	
[L3 Customization]		
[Live View]		
↳[Electronic Level Type]		
[Live View]		
↳[Electronic Level Design]		
[Live View]		
↳[Shooting Info Display]		
↳[L1 Customization]		
[L2 Customization]		
[L3 Customization]		
[Live View]		
↳[Shooting Info Display]		
↳[L1 Customization]		
[L2 Customization]		
[L3 Customization]		
[Live View]		
↳[Flicker Reduction]		
 2	AF/AE Lock Settings	
	E-Dial Programming	Movie

















PENTAX K-70

PENTAX K-3 III

▶ 1 Slideshow		▶ 2 Protect	Protect All Images
Protect All Images		▶ 2 Delete	Delete All Images
Delete All Images		C 4 Zoom Review	Quick Zoom
Quick Zoom		▶ 1 Playback Sound Volume	
Playback Sound Volume	Auto Image Rotation	▶ 1 Auto Image Rotation	
LCD Display	Grid Display	C 4 Monitor Display	[Playback Info Display] └[Standard Info. Display] [No Information Display]
	Highlight Alert		Grid Guide
			[Playback Info Display] └[Standard Info. Display] [No Information Display]
↶ 1 Language/言語		↶ 7 Language/言語	
Date Adjustment		↶ 7 Date Adjustment	
World Time			
Text Size			
Sound Effects		↶ 3 Sound Effects Volume	
		↶ 3 Sound Effects Setting	
↶ 2 LCD Display Settings		↶ 2 Monitor Adjustment	
Outdoor View Setting		↶ 2 Outdoor View Setting	
Night Vision LCD Display		↶ 2 Night Vision Display	
Indicator Lamps		↶ 3 Indicator Lamps	
↶ 3 Wi-Fi		↶ 4 Wireless LAN Setting	
GPS/E-Compass	GPS Time Sync		
	Calibration	↶ 4 GPS Settings	
USB Connection		↶ 4 USB Setting	
HDMI Out			
External Input Devices			
Auto Power Off		↶ 5 Auto Power Off	
↶ 4 Create New Folder		↶ 1 Create New Folder	
Folder Name		↶ 1 Folder Name	
File Name		↶ 1 File Name	
File No.	Sequential Numbering	↶ 1 Sequential Numbering	
	Reset File Number	↶ 1 Reset Numbering	
Copyright Information	Embed Copyright Data	↶ 1 Copyright Information	Embed Copyright Data
	Photographer		Photographer
	Copyright Holder		Copyright Holder
Format		↶ 1 Format	
↶ 5 Pixel Mapping		↶ 6 Pixel Mapping	
Dust Removal		↶ 6 Dust Removal	
Sensor Cleaning		↶ 6 Sensor Cleaning	
Certification Marks		↶ 6 Certification Marks	
Firmware Info/Options		↶ 6 Firmware Info/Options	
Reset		↶ 8 Reset	

PENTAX K-70

PENTAX K-3 III

C 1	EV Steps	C 5	EV Steps	
	Sensitivity Steps	C 5	ISO Sensitivity Steps	
	Meter Operating Time	C 5	Meter Operating Time	
	Auto EV Compensation		2 Auto EV Compensation	
	Link AE and AF Point		2 Link AE and AF Point	
	AE-L with AF Locked		2 Link AE and AF Point	
	Bulb (B) Mode Options	C 2	AF/AE Lock Settings	
C 2	Release While Charging	C 5	Bulb (B) Mode Options	
	AF with Remote Control			
	Bracketing Order	C 6	AF with Remote Control	
	One-Push Bracketing		4 Drive Mode	[Drive] ↳[Bracketing] ↳[Bracketing Order]
	Interval Shooting Options		4 Drive Mode	[Drive] ↳[Bracketing] ↳[One-Push Bracketing]
	AF in Interval Shooting		4 Drive Mode	[Drive] ↳[Interval Shooting] ↳[Interval Composite] ↳[Fixed Time Release]
	WB Adjustable Range		4 Drive Mode	[Drive] ↳[Interval Shooting] ↳[Interval Composite] ↳[AF Operation per Shot]
C 3	AWB in Tungsten Light		3 Auto Adjust. for Source	
	WB When Using Flash		3 Auto Adjust. for Source	
	Color Temperature Steps		3 AWB in Tungsten Light	
	4-way Controller Settings		3 AWB in Tungsten Light	
	Auto SR Off			
	Save Rotation Info	C 6	Color Temperature Steps	
	Save Menu Location			
C 4	Catch-in Focus		7 Auto Shake Reduction Off	
	AF Fine Adjustment		7 Auto Shake Reduction Off	
	Using Aperture Ring	C 6	Save Rotation Info	
	Reset Custom Functions		2 Store Cursor Position	
			1 AF with Viewfinder	Catch-in Focus
	C 7	AF Fine Adjustment		
	C 6	Using Aperture Ring		
		8 Reset		