




PENTAX K-3 II

























PENTAX K-3 III

1	Exposure Mode		USER
	Memory Card Options		
	Image Capture Settings	File Format	
		JPEG Recorded Pixels	
		JPEG Quality	
		RAW File Format	
	AF Assist Light		
	Digital Filter		
	HDR Capture		
	Pixel Shift Resolution		
2	Lens Correction	Distortion Correction	
		Lat-Chromatic-Ab Adj	
		Peripheral Illumin. Corr.	
		Diffraction Correction	
	D-Range Settings	Highlight Correction	
		Shadow Correction	
	ISO AUTO Setting		
	High-ISO NR		
	Slow Shutter Speed NR		
	Program Line		
GPS	GPS Logging		
	ASTROTRACER		
	Precise Calibration		
	Calibration		
	[Additional Settings] └[GPS Time Sync]		
	[Additional Settings] └[GPS Indicator Lamp]		
3	Contrast AF	Focus Peaking	
		Grid Display	
	Live View	Histogram Display	
		Highlight Alert	
	Composition Adjust.		
	1	Exposure in User Mode	
5		Memory Card Options	
		File Format	
		JPEG Recorded Pixels	
		JPEG Quality	
		RAW File Format	
AF Assist Light			
Digital Filter			
HDR Capture			
Pixel Shift Resolution			
6	Lens Correction	Distortion Correction	
		Lat-Chromatic-Ab Adj	
		Peripheral Illumin. Corr.	
		Diffraction Correction	
	D-Range Correction	Highlight Correction	
		Shadow Correction	
	ISO Sensitivity Setting		
	Noise Reduction	Slow Shutter Speed NR	
		High-ISO Noise Reduction	
	Program Line		
/			
4	ASTROTRACER		
	ASTROTRACER		
4	ASTROTRACER		
	Precise Calibration		
4	GPS Settings		
	/		
3	Indicator Lamps		
	1	AF with Live View	
AF Active Area			
Face Detection			
4	Monitor Display	Focus Peaking	
		[Live View] └[Shooting Info Display] └└[L1 Customization] └└└[L2 Customization] └└└└[L3 Customization]	
		Grid Guide	
		[Live View] └[Shooting Info Display] └└[L1 Customization] └└└[L2 Customization] └└└└[L3 Customization]	
		[Live View] └[Shooting Info Display] └└[L1 Customization] └└└[L2 Customization] └└└└[L3 Customization]	
	Composition Adjustment		

PENTAX K-3 II

PENTAX K-3 III

 3	Viewfinder		
	Electronic Level	Live View	
	Horizon Correction		
	AA Filter Simulator		
	Shake Reduction		
Input Focal Length			
 4	Instant Review	Display Time	
		Zoom Review	
		Save RAW Data	
		Delete	
		Histogram Display	
		Highlight Alert	
Digital Preview			
E-Dial Programming			
Button Customization	RAW/Fx Button		
	AF Button		
	Preview Dial		
Memory			
Save USER Mode	Save Settings		
	Rename USER Mode		
	Check Saved Settings		
	Reset USER Mode		
 1	Exposure Setting		
	Memory Card Options		
	Movie Capture Settings	Recorded Pixels	
		Framerate	
	Recording Sound Level		
	Digital Filter		
	HDR Capture		
	Movie SR		

 4	Viewfinder Display	[Viewfinder Screen] ↳[F1 Customization] [F2 Customization] [F3 Customization] [F4 Customization] Electronic Level Type	
	 4	Monitor Display	[Live View] ↳[Shooting Info Display] ↳[L1 Customization] [L2 Customization] [L3 Customization] [Live View] ↳[Electronic Level Type] [Live View] ↳[Electronic Level Design]
 7			Auto Horizon Correction
 4			AA Filter Simulator
 7			Shake Reduction
 6	MF Lens Focal Length		
	 4	Instant Review	Display Time
Zoom Review			
Save RAW (RAW Button)			
Delete Img. (Delete Btn.)			
Histogram			
Highlight Alert			
 2	Preview Dial	Digital Preview Settings	
 2	E-Dial Programming	Still Image	
		Rotation Direction	
 2	Fx Button		
 2	AF/AE Lock Settings		
 2	Preview Dial		
 5	Memory		
 1	Save User Mode Settings		
 1	Rename User Mode		
 1	Reset User Mode Settings		
	Live View		
 5	Memory Card Options		
	 5	Recorded Pixels	
 5		Framerate	
 5	Recording Sound Level		
 6	Digital Filter		
 4	HDR Capture		
 7	Shake Reduction		














PENTAX K-3 II

PENTAX K-3 III

1 Slideshow		4 Zoom Review	Quick Zoom
Quick Zoom		4 Monitor Display	[Playback Info Display └[Standard Info. Display └[No Information Display]
Highlight Alert		1 Auto Image Rotation	
Auto Image Rotation		2 Protect	Protect All Images
Protect All Images		2 Delete	Delete All Images
Delete All Images		7 Language/言語	
1 Language/言語		7 Date Adjustment	
Date Adjustment			
World Time			
Text Size		3 Sound Effects Volume	
Sound Effects		3 Sound Effects Setting	
	Guide Display	2 Guide Display	
LCD Display	Auto Screen Rotation	4 Monitor Display	[Status Screen └[Auto Display Rotation]
	Display Color	4 Monitor Display	Color Settings
	LCD Display Settings	2 Monitor Adjustment	
2 USB Connection		4 USB Setting	
HDMI Out			
Folder Name		1 Folder Name	
Create New Folder		1 Create New Folder	
File Name		1 File Name	
File No.	Sequential Numbering	1 Sequential Numbering	
	Reset File Number	1 Reset Numbering	
	Copyright Information	1	Embed Copyright Data
	Photographer		Photographer
	Copyright Holder		Copyright Holder
3 Flicker Reduction		4 Monitor Display	[Live View └[Flicker Reduction]
Auto Power Off		5 Auto Power Off	
Select Battery	Select Battery	5 Battery Grip Settings	
	AA Battery Type		
Wireless Memory Card		4 Wireless LAN Setting	
Reset		8 Reset	
4 Pixel Mapping		6 Pixel Mapping	
Dust Alert			
Dust Removal		6 Dust Removal	
Sensor Cleaning		6 Sensor Cleaning	
Format		1 Format	
Firmware Info/Options		6 Firmware Info/Options	

PENTAX *K-3 II*

PENTAX *K-3 III*

C 1	EV Steps	C 5	EV Steps
	Sensitivity Steps	C 5	ISO Sensitivity Steps
	Meter Operating Time	C 5	Meter Operating Time
	AE-L with AF Locked	C 2	AF/AE Lock Settings
	Link AE and AF Point	 2	Link AE and AF Point
	Auto EV Compensation	 2	Auto EV Compensation
	Bulb (B) Mode Options	C 5	Bulb (B) Mode Options
C 2	Bracketing Order	 4	Drive Mode [Drive] └[Bracketing] └[Bracketing Order]
	One-Push Bracketing	 4	Drive Mode [Drive] └[Bracketing] └[One-Push Bracketing]
	WB Adjustable Range	 3	Auto Adjust. for Source
	WB When Using Flash	 3	Auto Adjust. for Source
	AWB in Tungsten Light	 3	AWB in Tungsten Light
	Color Temperature Steps	 3	AWB in Tungsten Light
	Superimpose AF Area	C 6	Color Temperature Steps
C 3	AF.S Setting	C 4	[Viewfinder Screen] └[F1 Customization] [F2 Customization] [F3 Customization] [F4 Customization] Viewfinder Light
	1st Frame Action in AF.C	 1	AF.S Setting
	Action in AF.C Continuous	AF with Viewfinder	1st Frame Action in AF.C
	Hold AF Status		Action in AF.C Cont.
	AF with Remote Control		Hold AF Status
	Color Space		C 6
	LCD Panel Illumination	 5	Color Space
C 4	Save Rotation Info	C 4	LCD Panel Illumination Brightness LCD Panel Illumination
	Save Menu Location	C 6	Save Rotation Info
	Catch-in Focus	 2	Store Cursor Position
	AF Fine Adjustment	 1	AF with Viewfinder Catch-in Focus
	Using Aperture Ring	C 7	AF Fine Adjustment
	Reset Custom Functions	C 6	Using Aperture Ring
		 8	Reset