

PENTAX K-3




PENTAX K-3 III

























	1	Exposure Mode	USER
	Memory Card Options		
	Image Capture Settings	File Format	
		JPEG Recorded Pixels	
		JPEG Quality	
		RAW File Format	
	AF Assist Light		
	Digital Filter		
	HDR Capture		
	Lens Correction	Distortion Correction	
Lat-Chromatic-Ab Adj			
Peripheral Illumin. Corr.			
2	D-Range Settings	Highlight Correction	
		Shadow Correction	
ISO AUTO Setting			
High-ISO NR			
Slow Shutter Speed NR			
Program Line			
GPS	[ASTROTRACER]	[]	
	↳ [Action in B Mode]	[]	
	[ASTROTRACER]	[]	
	↳ [Precise Calibration]	[]	
	[ASTROTRACER]	[]	
	↳ [Timed Exposure]	[]	
	[ASTROTRACER]	[]	
↳ [Exposure Time]	[]		
[ASTROTRACER]	[]		
↳ [GPS LED Indicators]	[]		
Calibration			
GPS Time Sync			
3	Contrast AF		
	Focus Peaking		
	Grid Display		
	Histogram Display		
Highlight Alert			
Composition Adjust.			

C 1	Exposure in User Mode	
	5	Memory Card Options
	5	File Format
	5	JPEG Recorded Pixels
	5	JPEG Quality
	5	RAW File Format
	1	AF Assist Light
	6	Digital Filter
	4	HDR Capture
	6	Lens Correction
		Distortion Correction
		Lat-Chromatic-Ab Adj
	6	Peripheral Illumin. Corr.
		D-Range Correction
	6	Highlight Correction
		Shadow Correction
	2	ISO Sensitivity Setting
	6	Noise Reduction
		Slow Shutter Speed NR
		High-ISO Noise Reduction
	2	Program Line
	4	ASTROTRACER
		ASTROTRACER
	4	Precise Calibration
		Status Screen
		Status Screen
	3	Indicator Lamps
	4	GPS Settings
	1	AF with Live View
		AF Active Area
		Face Detection
		Focus Peaking
C 4	[Live View]	↳ [Shooting Info Display]
		↳ [L1 Customization]
		[L2 Customization]
		[L3 Customization]
	Grid Guide	
	[Live View]	↳ [Shooting Info Display]
		↳ [L1 Customization]
		[L2 Customization]
		[L3 Customization]
	[Live View]	↳ [Shooting Info Display]
↳ [L1 Customization]		
[L2 Customization]		
[L3 Customization]		
	7	Composition Adjustment

PENTAX K-3

PENTAX K-3 III

 3		Viewfinder
	Electronic Level	Live View
	Horizon Correction	
	AA Filter Simulator	
	Shake Reduction	
Input Focal Length		
 4	Instant Review	Display Time
		Zoom Review
		Save RAW Data
		Delete
		Histogram Display
		Highlight Alert
Digital Preview		
E-Dial Programming		
Button Customization	RAW/Fx Button	
	AF Button	
	Preview Dial	
Memory		
Save USER Mode	Save Settings	
	Rename USER Mode	
	Check Saved Settings	
	Reset USER Mode	
 1	Exposure Setting	
	Memory Card Options	
	Movie Capture Settings	Recorded Pixels
		Framerate
	Recording Sound Level	
	Digital Filter	
	HDR Capture	
	Movie SR	

 4	Viewfinder Display	[Viewfinder Screen] ↳[F1 Customization] [F2 Customization] [F3 Customization] [F4 Customization] Electronic Level Type
	 4	Monitor Display
 7 Auto Horizon Correction		
 4 AA Filter Simulator		
 7 Shake Reduction		
 6	MF Lens Focal Length	
 4	Instant Review	Display Time
		Zoom Review
		Save RAW (RAW Button)
		Delete Img. (Delete Btn.)
		Histogram
		Highlight Alert
 2	Preview Dial	Digital Preview Settings
 2	E-Dial Programming	Still Image
		Rotation Direction
 2	Fx Button	
 2	AF/AE Lock Settings	
 2	Preview Dial	
 5	Memory	
 1	Save User Mode Settings	
 1	Rename User Mode	
 1	Reset User Mode Settings	
 1	Live View	
 5	Memory Card Options	
		Recorded Pixels
 5	Framerate	
 5	Recording Sound Level	
 6	Digital Filter	
 4	HDR Capture	
 7	Shake Reduction	

PENTAX K-3













PENTAX K-3 III

▶ 1	Slideshow	
	Quick Zoom	
	Highlight Alert	
	Auto Image Rotation	
	Protect All Images	
	Delete All Images	
↷ 1	Language/言語	
	Date Adjustment	
	World Time	
	Text Size	
	Sound Effects	
	LCD Display	Guide Display
		Auto Screen Rotation
		Display Color
	LCD Display Settings	
	↷ 2	USB Connection
HDMI Out		
Folder Name		
Create New Folder		
File Name		
File No.		Sequential Numbering
		Reset File Number
Copyright Information		Embed Copyright Data
		Photographer
		Copyright Holder
↷ 3	Flicker Reduction	
	Auto Power Off	
	Select Battery	Select Battery
		AA Battery Type
	Wireless Memory Card	
	Reset	
↷ 4	Pixel Mapping	
	Dust Alert	
	Dust Removal	
	Sensor Cleaning	
	Format	
	Firmware Info/Options	

C 4	Zoom Review	Quick Zoom
	C 4	Monitor Display
▶ 1 Auto Image Rotation		
▶ 2		Protect
▶ 2	Delete	Delete All Images
↷ 7	Language/言語	
	Date Adjustment	
/		
↷ 3	Sound Effects Volume	
	Sound Effects Setting	
↷ 2	Guide Display	
C 4	Monitor Display	[Status Screen] ↳[Auto Display Rotation]
	C 4	Monitor Display
↷ 2	Monitor Adjustment	
↷ 4	USB Setting	
/		
↷ 1	Folder Name	
↷ 1	Create New Folder	
↷ 1	File Name	
↷ 1	Sequential Numbering	
↷ 1	Reset Numbering	
↷ 1	Copyright Information	Embed Copyright Data
		Photographer
		Copyright Holder
C 4	Monitor Display	[Live View] ↳[Flicker Reduction]
	↷ 5 Auto Power Off	
↷ 5	Battery Grip Settings	
/		
↷ 4	Wireless LAN Setting	
↷ 8	Reset	
↷ 6	Pixel Mapping	
/		
↷ 6	Dust Removal	
↷ 6	Sensor Cleaning	
↷ 1	Format	
↷ 6	Firmware Info/Options	

PENTAX K-3

PENTAX K-3 III

C 1	EV Steps	C 5	EV Steps
	Sensitivity Steps	C 5	ISO Sensitivity Steps
	Meter Operating Time	C 5	Meter Operating Time
	AE-L with AF Locked	C 2	AF/AE Lock Settings
	Link AE and AF Point	 2	Link AE and AF Point
	Auto EV Compensation	 2	Auto EV Compensation
	Bulb (B) Mode Options	C 5	Bulb (B) Mode Options
C 2	Bracketing Order	 4	Drive Mode [Drive └[Bracketing └[Bracketing Order]]
	One-Push Bracketing	 4	Drive Mode [Drive └[Bracketing └[One-Push Bracketing]]
	WB Adjustable Range	 3	Auto Adjust. for Source
	WB When Using Flash	 3	Auto Adjust. for Source
	AWB in Tungsten Light	 3	AWB in Tungsten Light
	Color Temperature Steps	C 6	Color Temperature Steps
	Superimpose AF Area	C 4	Viewfinder Display [Viewfinder Screen └[F1 Customization [F2 Customization [F3 Customization [F4 Customization]] Viewfinder Light
C 3	AF.S Setting	 1	AF.S Setting
	1st Frame Action in AF.C	AF with Viewfinder	1st Frame Action in AF.C
	Action in AF.C Continuous		Action in AF.C Cont.
	Hold AF Status		Hold AF Status
	AF with Remote Control		C 6
	Release While Charging	 5	Color Space
	Color Space		
C 4	LCD Panel Illumination	C 4	LCD Panel Illumination Brightness LCD Panel Illumination
	Save Rotation Info	C 6	Save Rotation Info
	Save Menu Location	 2	Store Cursor Position
	Catch-in Focus	 1	AF with Viewfinder Catch-in Focus
	AF Fine Adjustment	C 7	AF Fine Adjustment
	Using Aperture Ring	C 6	Using Aperture Ring
	Reset Custom Functions	 8	Reset