How to select [Fine Sharpness 2]

<Firmware version 1.00 or 1.01>

1. Press the four-way controller right in Capture mode.

2. The Custom Image option screen appears.

3. Select [Sharpness] or [Fine Sharpness] by turning Rear e-dial.

<Firmware version 1.02>

1. Press the four-way controller right in Capture mode.

2. The Custom Image option screen appears.

3. Select [Sharpness], [Fine Sharpness] or **[Fine Sharpness2]** by turning Rear e-dial.