

PENTAXTM Optio T10

PC Connection Manual

You can transfer images and movies captured with a digital camera to your computer and then organize, display, edit, print, and share them by installing the software included on the provided CD-ROM to your computer and connecting your digital camera to your computer with the USB cable. This section explains how to install the provided software "ACDSee for PENTAX" and the other necessary preparations for enjoying your digital camera pictures and movies on your computer. QuickTimeTM and QuickTime logo are trademarks used under license. The QuickTime logo is registered in U.S. and other countries.

Software Provided

Windows


- ACDSee for PENTAX 2.0 (Image viewing/editing software)
- ACD FotoSlate 3.0 (Image layout and printing software)
- ACD Showtime! for PENTAX (Movie editing software)
- QuickTime 7
- DirectX 9.0
- USB driver for Windows 98/98 SE

Macintosh

- ACDSee for PENTAX (Image viewing/editing software)



You are recommended to use an AC adapter connected to a power outlet when connecting the camera to a computer. If the battery runs out of power while images are being transmitted to the computer, the image data may be lost or damaged. When using an AC adapter, make sure that the AC plug cord is properly connected to the camera.



Windows, Macintosh Step 1

System Requirements

Windows System Requirements



The software cannot be used on Windows 95.

• USB connection

- OS : Windows 98/98 SE/Me/2000/XP (Home Edition/Professional) (USB driver must be installed on Windows 98/98 SE)
- USB port must be standard equipment

• Application Software

<ACDSee for PENTAX 2.0, ACD FotoSlate 3.0>

(Nine languages: English, French, German, Spanish, Italian, Russian, Chinese [traditional and simplified], Korean, Japanese)

- OS : Windows 98 SE/Me/NT/2000/XP (Home Edition/Professional)
- CPU : Pentium or higher recommended
- Memory : 64 MB minimum
- Hard Disk space : 40 MB minimum
- Internet Explorer 5.0 or later

* Some movies, such as those in .mov file format, require viewing with QuickTime 6 or later, DirectX 9.0 or later and Windows Media Player 7.1 or later.

* To install ACDSee for PENTAX 2.0, Windows Installer Service Version 2.0 may be required.

* ACD Showtime! for PENTAX is also installed when performing standard installation of ACDSee for PENTAX 2.0 (However, ACD Showtime! for PENTAX cannot be used if system requirements are not met.).

* Operation is not guaranteed on all PCs meeting the system requirements.

<ACD Showtime! for PENTAX>

(Six languages: English, French, German, Spanish, Italian, Japanese)

- OS : Windows 98 SE/Me/NT/2000/XP (Home Edition/Professional)
- CPU : Pentium III 500 MHz or higher (Pentium 4 2.0 GHz or higher recommended)

- Memory : 128 MB minimum (512 MB or higher recommended)
- Hard Disk space : 50 MB minimum
- Internet Explorer 5.0 or later
- QuickTime 6 or later
- Windows Media Player 7.1 or later
- DirectX 9.0 or later

<QuickTime 7>

(Eight languages: English, French, German, Spanish, Italian, Chinese [traditional and simplified], Korean, Japanese)

- OS : Windows 2000/XP (Home Edition/Professional)
- CPU : Pentium or higher recommended
- Memory : 128 MB minimum

* QuickTime 6 or later is required to play movies with the provided software ACDSee for PENTAX 2.0 or ACD Showtime! for PENTAX.

* QuickTime 7, which is included on the provided CD-ROM (S-SW45), can be installed only on Windows 2000/XP. QuickTime 6 is required to play QuickTime-compatible movies on Windows 98/98 SE/Me/NT.

The versions of Internet Explorer, Windows Media Player and Windows Installer Service required for use of ACDSee for PENTAX 2.0 and ACD Showtime! for PENTAX are not included in the provided CD-ROM (S-SW45). These can be downloaded from the following sites and installed.

- Internet Explorer
<http://www.microsoft.com/ie>
- Windows Media Player
<http://www.microsoft.com/windows/windowsmedia/>
- Windows Installer Service
<http://support.microsoft.com/default.aspx?scid=kb;EN-US;292539>

Macintosh System Requirements

• USB connection

- OS : Mac OS 9.2/X (10.1 or later)
- USB port must be standard equipment

* Installation of the driver is not necessary.

• Application Software

<ACDSee for PENTAX>

(Six languages: English, French, German, Spanish, Italian, Japanese)

- OS : Mac OS 9.2 or later (requires QuickTime 6 or later and the latest version of CarbonLib)

- CPU : PowerPC 266 MHz or higher
- Memory : 8 MB minimum
- Hard Disk space : 6 MB minimum

* Operation is not guaranteed on all PCs meeting the system requirements.

57615

01-200602 Printed in China

Windows Step 2

Installing the Software

Install the image viewing/editing software (ACDSee for PENTAX 2.0).



- Windows Media Player 7.1 or later must be installed in your PC to install ACDSee for PENTAX 2.0.
- When multiple accounts have been setup in Windows 2000 or Windows XP, log on with an account that has administrative rights before installing the software.

- 1 Turn your PC on.
- 2 Insert the CD-ROM (S-SW45) into the CD-ROM drive.

The PENTAX Software Installer screen appears.

If the PENTAX Software Installer screen does not appear

Display the PENTAX Software Installer screen following the steps below.

- 1) Double-click [My Computer] on the desktop.
- 2) Double-click the [CD-ROM drive (S-SW45)] icon.
- 3) Double-click the [Setup.exe] icon.

- 3 Choose a language from the displayed screen.

The software selection screen appears.



- 4 Install QuickTime and DirectX.

If the proper versions of QuickTime and DirectX are not installed in your PC, install them before installing ACDSee for PENTAX 2.0.

Click [Install] for QuickTime or DirectX, and then follow the on-screen guidance to install. When installation is completed, the software selection screen reappears.

* QuickTime 7, which is included on the provided CD-ROM (S-SW45), can be installed only on Windows 2000/XP.

- 5 Click [Install] for ACDSee for PENTAX.

Follow the on-screen guidance and enter the registration information when the Setup screen appears. Reboot your PC after installation is finished.



For Windows 98/98 SE:

A driver must be installed before using the USB cable to connect the camera to a computer.

- 1 Turn your PC on.
- 2 Insert the CD-ROM (S-SW45) into the CD-ROM drive.
- 3 With your camera turned off, connect it to your PC using the USB cable.
- 4 Turn your camera on.

Your PC will automatically detect the camera as new hardware and the Wizard screen will appear. Follow the on-screen guidance and install the USB driver.


* Make sure that you select [Search for the best driver for your device. (Recommended).] for the search method and check only [CD-ROM drive] for the search location when installing.



If the proper versions of Quick Time and DirectX are not installed on your PC:

A message, such as the one shown on the right, appears when ACDSee for PENTAX 2.0 is run. Click [Close] and install QuickTime and DirectX from the PENTAX Software Installer screen.

* If the proper versions of QuickTime and DirectX are not installed in your PC, operation of ACDSee for PENTAX 2.0 is not guaranteed.



If your PC is running Windows Media Player earlier than version 7.1:

A message, such as the one shown on the right, may appear during installation.

In this case, follow the instructions below to update Windows Media Player before installing the software.


- 1 Cancel installation of ACDSee for PENTAX.
- 2 Install the latest version of Windows Media Player.

The latest version can be downloaded from the following website.

<http://www.microsoft.com/windows/windowsmedia/>

To guarantee more efficient operation, you are recommended to update Windows from the following website after updating Windows Media Player.

<http://www.microsoft.com/windows/ie/default.msp>



The image layout and printing software "ACD FotoSlate 3.0" and the movie editing software "ACD Showtime! for PENTAX" are also installed when you install all program features of ACDSee for PENTAX 2.0 (complete installation).

Macintosh Step 2

Installing the Software


Install the image viewing/editing software (ACDSee for PENTAX).

- 1 Turn your Macintosh on.
- 2 Insert the CD-ROM (S-SW45) in the CD-ROM drive.
- 3 Double-click the CD-ROM (S-SW45) icon.
- 4 Double-click the [Install ACDSee] icon.

The PENTAX Software Installer screen appears. Double-click the [Master Installer] icon to display the PENTAX Software Installer screen.

- 5 Choose a language from the displayed screen.

The ACDSee for PENTAX installer screen appears.



If the message [CarbonLib-xxxxx could not be found] appears during installation:

You must add the extension file "CarbonLib" to the Extension folder in the System folder in order to install the provided software in Mac OS 9.2.

This message appears when this extension file does not exist or when an older version of the file exists.

The latest version of the CarbonLib file is available on the Apple website. Download the file and then install it.

Apple website: <http://www.apple.com/>


*Contact Apple for detailed information on how to use the CarbonLib file.

Windows, Macintosh Step 3

Setting Up Your Digital Camera

Setting the USB Connection Mode to [PC]

- 1 Press the MENU button.
- 2 Touch [Setting].
- 3 Touch [USB Connection].
- 4 Touch the icon.
- 5 Press the MENU button.
- 6 Press the button.




If the digital camera is connected to your PC in (PictBridge) USB Connection mode, the images cannot be transferred. Disconnect the USB cable from your camera and PC to set the USB Connection mode to (PC), and then reconnect the USB cable.

Product Registration on the Internet

Please click [Product Registration] on the software selection screen in **Step 2**.

A world map for Internet Product Registration is displayed.



If your PC is connected to the Internet, click the displayed country or region and then follow the instructions to register your product.

Thank you very much for your cooperation.



Only customers in displayed countries and regions can register their products on the Internet Product Registration.


Transferring Images to a Windows PC

When the digital camera is connected to your Windows PC and the camera is turned on, the PC automatically recognizes the camera and the confirmation dialog box for transferring images (the Device Detector screen) appears.

Connecting the Camera and PC

- 1 Turn your PC on.
- 2 With your camera turned off, connect it to your PC using the USB cable.

If there is no SD Memory Card in the camera, the images stored in the built-in memory will be transmitted to your PC.



- 3 Turn your camera on.
- The Device Detector screen appears automatically. If the Device Detector screen does not appear, display and copy the images following the steps in "When the Device Detector screen does not appear".

- You may be prompted to restart the system when connecting the camera to a PC for the first time.
- The power indicator blinks while the camera is connected to a PC with the USB cable.

Transferring Images

- 4 Confirm that [Acquire images from the device with ACDSee] is checked and click [OK].



- 5 Click [Next].



- 6 Select an image to copy and click [Next].



- 7 Specify the name and save destination of the image, and click [Next].

The image is copied to the PC.




- 8 Click [Finish].

The ACDSee for PENTAX 2.0 Browser starts.



When the Device Detector screen does not appear


- 4 Double-click the [ACDSee for PENTAX 2.0] icon on the desktop.



- 6 Double-click [Removable Disk].



- If the SD Memory Card has a volume label, the volume label name appears instead of [Removable Disk]. A new unformatted SD Memory Card may show the manufacturer name or model number.



- 7 Double-click the [DCIM] folder.
- Images are stored in folder [xxxPENTX], where "xxx" is a three-digit folder number. When [Folder Name] on the [View Setting] menu is set to [Date], folders are displayed with a folder name indicating the date the images were taken. Images taken on March 25, for example, are stored in folder [xxx_0325].



- 8 Select the folders you want to copy to the PC.
- Hold the [Ctrl] key on the keyboard while clicking on the folders in which the images you want to copy are stored.



















- 9 Select [Copy To Folder...] from the [Edit] menu.

The Copy Files screen appears.



- 10 Specify the destination folder.
- 11 Click [OK].

The image is copied to the PC.



Using the Software















Using ACDSee for PENTAX 2.0

ACDSee for PENTAX 2.0 lets you view, edit, organize, search for, share, and print images.

Starting ACDSee for PENTAX 2.0

- 1 Double-click the [ACDSee for PENTAX 2.0] icon on the desktop.

ACDSee starts and the main window, which is called the browser, appears.













Using ACD Showtime! for PENTAX

ACD Showtime! for PENTAX is a tool for creating slide show presentations combining videos, images and music and saving them as video files on the hard disc. ACD Showtime! provides a variety of transitions and effects for slide shows, editing tools for correcting images and tools for trimming videos and audio files.

- 1 Double-click the [ACD Showtime! for PENTAX] icon on the desktop.

ACD Showtime! starts and the [ACD Showtime! for PENTAX] screen appears.

- 2 Click [Create Video File].
- Follow the on-screen guidance. For details on how to use these functions, see the help pages.



Using ACDSee for PENTAX

ACDSee for PENTAX lets you view, edit, organize, search for, share, and print images.

Starting ACDSee for PENTAX

- 1 Double-click the [ACDSee] folder inside the [Applications] folder.
- 2 Double-click the [ACDSee for PENTAX] icon.

ACDSee starts and the main window, which is called the browser, appears.

