


[Enhanced Functions] of updated Firmware version 1.30 for K-1

1. Added [Electronic Shutter] for Live View shooting


- *You can select the mechanical shutter or the electronic shutter for Live View shooting.
- *If you choose the electronic shutter, it is able to reduce the minute camera shake of mechanical shutter.
- *It is selectable by MENU and [INFO] button.

By MENU:


- [1] Turn the camera on and press [MENU] button.
- [2] Select [LV Electronic Shutter] at the [Capture 2] menu




- [3] Press [Right] key, you can choose [ES on] or [ES off].



- [4] Press [Up] key to select [ES on].



- [5] Press [OK] key.




- [6] Press [MENU] button to clear the [MENU display].
Press [LV] button for the Live View shooting.

By [INFO] button:

Following the procedures of [Customizing the Control Panel] in Page 20 of the Operating Manual, register the [LV Electronic Shutter] on the Control Panel, so that the setting can be change by [INFO] button.

- [1] Press [LV] button to enter the Live View shooting.
- [2] Press [INFO] button to change the setting of [LV Electronic Shutter].



Caution:


- *The drive mode that can be used with Electronic Shutter are single frame shooting, Self-timer shooting (12s/2s), Remote Control shooting(Immediate/3s), Mirror up shooting and Multiple exposure.
- *The Shake Reduction function is fixed to OFF.
- *The HDR mode cannot use with Electronic Shutter.
- *The external flash is fixed to off (will not discharge)
- *The moving subject may be distorted on the image.
- *The flicker of fluorescent lamp or heavy movement of the subject may cause the corrupt image.

2. Added [1:1] angle of view for [Crop] function


It is selectable at the MENU, Smart Function and [INFO] button.

By MENU:


- [1] Turn the camera on, press [MENU] button.
- [2] Select [Crop] with Four-way controller at the [Capture 2] menu.



- [3] Press [Right] key and select screen is appeared.



- [4] Select [1:1] with Four-way controller



- [5] Press [OK].



By Smart Function:

- [1] Select [Crop] with the Function dial.





- [2] Change the function setting with setting dial.

It will change in order of AUTO <-> FF <-> APS-C <-> 1:1 <-> AUTO



By [INFO] button:



By [INFO] button:




3. Added [2 frames bracketing] in the [AA Filter Simulator bracketing]


It is selectable by MENU and [INFO] button

By MENU:


- [1] Turn the camera on and press [MENU] button.
- [2] Select [AA Filter Simulator] at [Capture 4] menu with Four-way controller.



- [3] Press [Right] key, the select screen is appeared.



- [4] Press Four-way controller and select [2 frames bracketing].



- [5] Press [OK] key.

4. Added [OFF (Cancel the Bracketing)] position in the [BKT] of the Smart Function.

By Smart Function:

- [1] Select [BKT] by the Function dial.
- [2] To turning the Setting dial, it can be change the range of bracketing or change to the [OFF (Cancel the bracketing)].

